



- Effective Stain
 Remover
- Approved by:IMO

DESCRIPTION

Carechlor is a high alkaline, chlorine based product for the removal of discoloration stains in cargo tanks caused by soot or red/ and or yellow dyed gasoline cargoes from epoxy and zinc based tank coatings.

ADVANTAGE

- Suitable on epoxy and zinc tank coatings
- Fast acting
- Biodegradable
- Does not contain nonyl phenol ethoxylates or other estrogenic compounds.
- Free from hydrocarbon solvents
- · Effective and economical in use

APPLICATIONS

Tank Cleaning

Carechlor is generally used for removing soot stain deposits from zinc and epoxy coated tanks. It is also very effective for bleaching of stains caused by the carriage of dyed gasoline cargoes.

Cargo Hold Cleaning

Carechlor is used to clean cargo holds after carrying cargoes such as pet coke, coal and mineral oil residues.



Marine Care BV
Dude Maasweg 35
Port number 4005
ti197 KJ Rotterdam Botlek
The Netherlands
The 1010 2950342

. +31 (0)10 2950345 . supply@marinecare.nl V. www.marinecare.nl

DIRECTIONS FOR USE TANK CLEANING

Carechlor is used in a 1-3% solution in fresh or seawater. Circulate at ambient temperatures for 2-4 hours. One solution usually is sufficient to clean 3-4 tanks. After this cleaning rinse thoroughly with a sufficient amount of fresh water.

DIRECTIONS FOR USE HOLD CLEANING

After sweeping and de-mucking apply Carechlor in a 10 - 50 % solution depending on the contamination.

Let the product soak for 30 minutes making sure not to let the solution dry on the surface. Then spray off with water.

Carechlor can be applied by the Caretech Hold Cleaning Kit.

PROPERTIES

Article number 14616 / 16616

pH (1 % solution) > 11 Density 1,20 g/cm³

Flashpoint None
Physical state Liquid

APPROVALS

• IMO approved in accordance with MEPC 590 Guidelines

For detailed information on safety and health, please refer to the Material Safety Data Sheet MSDS and/or product label.



CARECHLOR

- Effective Stain
 Remover
- Approved by:IMO



Marine Care BV
Oude Maasweg 35
Port number 4005
3197 KJ Rotterdam Botlek
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. supply@marinecare.nl

www.marinecare.nl