

CARECLEAN CEMENT REMOVER

For removal of cement deposits

- Eco-friendly
- Biodegradable
- Highly effective

DESCRIPTION

Careclean Cement Remover is a strong acid based product, specially designed for the removal of cement deposits from most common surfaces.

ADVANTAGE

- Fast and efficient cement removal
- Inhibits against acidic attack on cleaned ferrous surfaces
- Forms a protective layer on steel surfaces to which paint adheres readily
- Biodegradable
- Non flammable

APPLICATIONS

Careclean Cement Remover is used for removing cement residues from all common metal surfaces. It is not to be used on zinc, aluminium, galvanized materials and stainless steel.

Cargo Hold Cleaning

Careclean Cement Remover is used to clean cargo holds after carrying cement. After sweeping and demucking apply Careclean Cement Remover in a 10 - 50 % solution depending on the contamination. Let the product soak for 30 minutes making sure not to let the solution dry on the surface. Then spray off with water.

DIRECTIONS FOR USE

Apply Careclean Cement Remover with brush on surfaces to be cleaned.

- Use undiluted for hard cement deposits
- Use Careclean Cement Remover in a 10 - 50 % solution in water, depending on the thickness of the cement layer
- Rinse thoroughly with water, 10 to 15 minutes after application

discover the difference



DOSAGE

See directions for use.

PROPERTIES

| | |
|-------------------|------------------------|
| Article number | 14205 |
| pH (1 % solution) | 1,0 |
| Density | 1,15 g/cm ³ |
| Flashpoint | Not applicable |
| Physical state | Liquid |

APPROVALS

All our supplied hold cleaning chemicals are IMO approved & comply with the set Marpol MEPC 63/23/add. 1, Annex 24 resolution MEPC.219(63) – Annex V – 2012 guidelines adopted March 2012.

For detailed information on safety and health, please refer to the Material Safety Data Sheet MSDS and/or product label.

CARECLEAN CEMENT REMOVER

- Eco-friendly
- Biodegradable
- Highly effective

discover the difference

MARINE CARE BV
Mozartlaan 3
3144 NA Maassluis
The Netherlands
T. +31 (0)10 2950342
F. +31 (0)10 2950345
E. supply@marinecare.nl
W. www.marinecare.nl